



Standard Merge Cross-Transfer

Motorized Roller Conveyor

I/O Configuration

Merge Zone: Input 1, Output 1

Belt Motor (Direction): Output 6

Belt Motor (Up/Down): Output 4, Output 5