

# Termination Board pn 7525 For MotEnc-Lite

VITAL Systems Inc USA

[www.VSI99.com](http://www.VSI99.com)  
[sales@VSI99.com](mailto:sales@VSI99.com)

Encoder Ribbon  
Connector IDC Pinouts:

(J2, J4, J6, J8)

- |        |        |
|--------|--------|
| 1: GND | 2: PWR |
| 3: A-  | 4: A+  |
| 5: B-  | 6: B+  |
| 7: X-  | 8: X+  |
| 9: NC  | 10: NC |

\* GND is common with PC ground  
\* PC PWR = 5Volts from PC  
\* PC PWR IS USED TO POWER THE ENCODERS IF JUMPERS J12 are INSTALLED. To use more that 5 Volts to power the Encoders, remove J12 to disconnect PWR from PC 5 Volts. Then apply maximum 12 Volts to PWR and GND to power Encoders.

